

Configure DDNS in MB8000

As the IP address of MB8000 may vary each time when it dials up. You may feel inconvenient to check the IP address each time. MB8000 offers a Dynamic Domain Name System (DDNS) feature. DDNS lets you assign a fixed host and domain name to a dynamic Internet IP address. It is useful when you are hosting your own website, FTP server, or other server through dial up link.

Before you can use this feature, you need to sign up for DDNS service at www.staticcling.org or www.DynDNS.com, currently MB8000 supports these two DDNS service providers. It only takes a couple of minutes for you to establish an account for a MB8000:

- Go to <http://www.staticcling.org>
- Click on “new” to register a new host (e.g. MB8000 for Top Global).
- Fill in your info and use whatever naming convention you want for the “hostname” field. This is the name you will use to reach the given MB8000
 - e.x. Login (hostname): **topglobal** <- easy to remember and will eventually translate to <http://topglobal.staticcling.org>.
- Make sure to respond to the automated email to activate the DDNS entry.

The next step is to configure the MB8000. This also only takes a couple of minutes.

- Go to the advanced screen and near the bottom you’ll see the DDNS button
- Enter the hostname from step one above (e.g. topglobal)
- Select StaticCling.org as the DDNS provider

Setup — DDNS — DDNS setting

Status:

Provider:

User Name:

Password:

After you configured the right DDNS configuration, each time when MB8000 dial up, the Domain Name you applied in the DDNS service provider will be directed to the new IP address MB8000 got. You just need to remember the domain name of MB8000 to access it.



ADDR: 21072 Bake Parkway, Suite 106, Lake Forest, CA
92630, USA

TEL: +1 949 586 7046; +86-010-64390528

TOP Global USA, Inc.

FAX: +86-010-64392901

<http://www.topglobalusa.com/>
